

# SERVICE MANUAL



PLACE SERIAL NUMBER LABEL HERE

**BAY  TEK**  
entertainment

# FACTORY CONTACT INFORMATION



BAY TEK ENTERTAINMENT  
Pulaski Industrial Park  
1077 East Glenbrook Drive  
Pulaski, WI 54162 USA

## SIGN UP TO RECEIVE OUR E-MAILS!

Stay up to date on the latest game information, new products launches, early notification of parts specials, updates of retro fit parts, software upgrades, best practices and more!

Visit [baytekent.com](http://baytekent.com) and enter your email to sign up!

You can also register your new game at [baytekent.com/register](http://baytekent.com/register)

### SALES

Phone: (920) 822-3951  
Fax: (920) 822-8936  
Email: [sales@baytekent.com](mailto:sales@baytekent.com)

### PARTS

Phone: (920) 822-3951 Ext 1101  
Fax: (920) 822-1496  
Email: [parts@baytekent.com](mailto:parts@baytekent.com)

### SERVICE

Phone: (920) 822-3951 Ext 1102  
Fax: (920) 822-1496  
Email: [service@baytekent.com](mailto:service@baytekent.com)

**Open Monday - Friday**  
**8 AM - 5PM C.S.T.**

All games are proudly manufactured at our factory in Pulaski, Wisconsin, USA

# TABLE OF CONTENTS

FACTORY CONTACT INFORMATION .....	2
TABLE OF CONTENTS.....	3
WELCOME TO Connect 4 Hoops HD .....	4
GAME SPECIFICATIONS .....	5
SAFETY PRECAUTIONS .....	5
GAME SET UP .....	6 - 21
HOW TO PLAY .....	22
MAIN MENU FUNCTIONS .....	23
VOLUME & ATTRACT .....	24
GAME SETTINGS .....	25
PAYOUT SETTINGS .....	26
TICKET PATTERNS .....	27
STATISTICS .....	27
DIAGNOSTICS .....	28
CARD SWIPE INSTALLATION .....	29
CIRCUIT BOARD LAYOUT .....	30
WIRING DIAGRAMS .....	31 - 38
DIAGNOSTICS .....	39 - 44
HOOPS NOT SCORING .....	45
POWER SUPPLY DIAGNOSTICS .....	46
BILL ACCEPTOR DIAGNOSTICS .....	47
I/O AUX BOARD PINOUT .....	47
HOW TO ACCESS BALL SENSOR .....	48
HOW TO ACCESS REAR CONTROL BOARD .....	48
HOW TO ACCESS BALL GATE MOTOR & SENSOR .....	48
MONITOR DEFAULT SETTINGS .....	49
HOW TO REPLACE MONITOR .....	50 - 51
HOW TO MOVE MARQUEE TO TOP OF GAME .....	52
HOW TO UPDATE SOFTWARE .....	53
AVAILABLE BLANKING PLATES .....	53
DIPSWITCH SETTINGS .....	54
BALL GATE EXPLODED VIEW .....	55 - 56
PARTS LIST .....	57 - 58
PARTS PICTURES .....	58 - 60
DECAL DIAGRAM .....	61
MAINTENANCE LOG .....	62
TECHNICAL SUPPORT .....	63
WARRANTY .....	64

# WELCOME TO CONNECT 4 HOOPS HD

## **Congratulations on your purchase!**

Please take a moment to read through this manual and be sure to contact us if you have any questions, or would like more information.

Thank you for your purchase! Your business is important to us and we hope you enjoy this game as much as we do!

*Your Friends at Bay Tek Entertainment*



Licensed by:



## GAME INSPECTION

Please inspect the game for any damaged, loose, or missing parts.

If damage is found, please contact your freight carrier first.  
Then, contact Bay Tek Entertainments' Service Department at  
(920) 822-3951 Ext. 1102  
Or email us at [service@baytekent.com](mailto:service@baytekent.com) for further assistance.

# GAME SPECIFICATIONS

WEIGHT		
NET WEIGHT	1000lbs.	454 kg
SHIP WEIGHT	1270 lbs.	576 kg
GAME DIMENSIONS		
WIDTH	61"	155 cm
DEPTH	112"	285 cm
HEIGHT	108"	275 cm
OPERATING TEMPERATURE		
FAHRENHEIT	45 - 80 F	
CELSIUS	7.2 - 26.7 C	
SHIPPING DIMENSIONS		
PALLET # 1	76"x 54"x 86"	860 lbs. class 125
PALLET # 2	76"x 34"x 86"	410 lbs. class 250

POWER REQUIREMENTS			
INPUT VOLTAGE RANGE	100 to 120 VAC		220 to 240 VAC
INPUT FREQUENCY RANGE	60 Hz		50 Hz
MAX OPERATING CURRENT			
3.3 AMPS @ 115 VAC / 1.9 AMPS @ 230VAC			

# SAFETY PRECAUTIONS

NOTICE	
Modifications to the mechanical, electrical and structural components of this game may void its compliance certifications.	
This appliance is suitable for INDOOR, DRY locations only.	
DANGER	
DO NOT perform repairs or maintenance on this game with the power ON. Unplug the unit from the wall outlet or shut off the power strip located inside the cabinet.	
WARNING	
Use of flammable substances can cause sever burns or serious injury. Always use NON-FLAMMABLE solvents for cleaning. DO NOT use gasoline kerosene or thinners.	
CAUTION	
Lifting heavy objects can cause back, neck or other injuries. Be sure adequate lifting and moving devices are available when unloading, unpacking and moving this game.	
ATTENTION	
Be sure the electrical power matches the game requirements. See the serial number located on the back of the game cabinet. Always plug into a grounded circuit. If the supply cord is damaged, it must be replaced by an approved cord or assembly provided by the manufacturer. A shielded power cable must be used for the game to retain EU/EMC compliance.	
IN CASE OF EMERGENCY	
UNPLUG THE POWER CORD. The power cord must be accessible at all times in case of an emergency.	



# CONNECT 4 HOOPS HD SETUP

## SECTION ASSEMBLY


UPPER REAR  
CABINET



LOWER REAR  
CABINET



MIDDLE CABINET



MARQUEE SECTION



FRONT CONSOLE




# Connect 4 Hoops HD Shipping Checklist Game Serial # \_\_\_\_\_




## Large Pallet Parts List:

- ☐ Large Pallet 76"x 54"x 86" 860 lbs. class 125
- ☐ 2 Side Cages Part 5 (Part # AAME15019)
- ☐ Middle Cabinet Part B
- ☐ Lower Rear Cabinet Part N



- ☐ Cardboard Box # 2 (76 1/2" by 30" by 9 1/2")  
(Box packed in this order:)
- ☐ Right Side Front Upright Part H
- ☐ Left Side Front Upright Part K
- ☐ Top Front Part L
- ☐ 2 of Wood Corner Pieces Part J
- ☐



2 of Front Top Connector Plate Part 4 (Part # A5ME15001)

- ☐ Round Marquee Assembly Part P
- ☐



Inspected By: \_\_\_\_\_

Inspected Date: \_\_\_\_\_

Please email this form to [parts@baytekent.com](mailto:parts@baytekent.com) if any discrepancies are found.







# Connect 4 Hoops HD Shipping Checklist Game Serial # \_\_\_\_\_



## Small Pallet Parts List:

- ☐ Small Pallet 76"x 34"x 86" 410 lbs. class 250
- ☐ Front Console Part M
- ☐ 6 Game Balls (Part # A5BA15000)
- ☐ Service Manual
- ☐ Hardware Kit (Part # A5KIT-HOOPS/HD)
- ☐ AC Power Cord (Part # A5CORD5-A)
- ☐ Game keys
- ☐ Upper Rear Cabinet Part O
- ☐ Wood Platform Part A
- ☐ Cardboard Box # 1 (64" by 30" by 7")  
(Box packed in this order:)
- ☐ Front Windshield (Part # WACA15014)
- ☐ 3 of Game Roof Boards Part G
- ☐ Left Side of Middle Section Part E
- ☐ Right Side of Middle Section Part F
- ☐ Wood Diverter Part C
- ☐ Wood Diverter Part D
- ☐ 2 of Rear Connector Plates Part 1 (Part # A5ME15010)
- ☐ 2 of Middle Connector Plates Part 2 (Part # A5ME15004)
- ☐ 2 of Middle Connector Plates Part 3 (Part # A5ME15004)



Inspected By: \_\_\_\_\_

Inspected Date: \_\_\_\_\_

Please email this form to [parts@baytekent.com](mailto:parts@baytekent.com) if any discrepancies are found.



# CONNECT 4 HOOPS HD SETUP

The game will arrive on 2 pallets with 2 cardboard boxes of parts. Please inspect the pallets for shipping damage and report immediately to the freight company if any damage found. There will be about 5 hours of assembly time needed.

## Tools Needed:

1 step ladder (6 foot)

2 of 9/16" Wrenches

1" Crescent Wrench

3 people

7/16" Wrench

# 3 Phillips screwdriver bit

# 2 Square head screwdriver bit

## Important:

Portions of this game are heavy, bulky and large. Assembly requires 3 people to lift heavy components, and ladders that are tall and strong enough to position components to the top of the game.

The 6 Game Balls, Service Manual, Hardware Kit, and Power Cord are located in this area of the front console.

Game keys are also located in this area.



From the large pallet, unwrap and unbox the following parts:

Cardboard Box # 2 - set aside for later use.


2 sections of side cages - set aside for later use.

Middle cabinet - Remove the wood blocks holding this to the pallet.

Set middle cabinet aside for later use.

Lower rear cabinet - Remove the wood blocks holding this to the pallet.

Position the lower rear cabinet in position upright about 6 feet away from the wall.



# CONNECT 4 HOOPS HD SETUP

From the small pallet, unwrap and remove Cardboard Box # 1 - set aside for later use.


Using 3 people, remove the wood platform (Part A) from the shipping configuration by removing the 4 Phillips bolts. (2 on each side)  
2 people should hold and support the wood as bolts are removed.  
Remove the part A and set aside for later use.

The 6 Game Balls, Service Manual, Hardware Kit, and Power Cord are located in this area of the front console.  
**Game keys are also located in this area.**


Using 3 people, remove the Upper rear Cabinet from the shipping configuration by removing the 8 Phillips bolts. (4 on each side)  
2 people should hold and support the wood as bolts are removed.  
Set the Upper Rear Cabinet aside for later use.

The support wood should be removed from the Front Console. This support wood is not used in game assembly.

Remove the Front Console from the pallet by removing the wood blocks holding this to the pallet. Set aside for later use.




Using 2 people, position upper rear cabinet behind lower rear cabinet, which is in place, about 6 feet away from the wall.



# CONNECT 4 HOOPS HD SETUP

Carefully lift upper rear cabinet up onto the top of the bottom rear cabinet. It will slide into position as shown.



Locate the 2 of metal rear connector plates. Part 1 from box # 1.

Install the plates on both sides of the cabinet with 12 of the black 1/4-20 X 1 Phillips head bolts using a # 3 Phillips Head bit. (6 per side)




Locate the power cord from the front console and plug from the line filter in back of the game to the wall outlet.

Position the assembled rear cabinet up against wall in final game position.




## Assemble middle cabinet section:

Tip middle section down horizontal as shown:




# CONNECT 4 HOOPS HD SETUP


Locate part C (wood diverter) from box # 1 and affix to part B as shown with 4 of black 10 X 5/8" screws using a # 2 Square Head bit.



Similarly, locate part D (wood diverter) from box # 1 and affix to part B as shown with 4 of black 10 X 5/8" screws using a # 2 Square Head bit.



Locate part E (left side) from box # 1 and affix to part B as shown with 3 of black #8 X 1 1/4" Bugle screws using a # 2 Square Head bit



Ensure the front and rear edge of part E is aligned properly with the lower cabinet.

This will be carefully balanced until the other side and top plate is attached.






# CONNECT 4 HOOPS HD SETUP

Similarly, locate part F (right side) from box # 1 and affix to part B as shown with 3 of black #8 X 1¼" Bugle screws using a # 2 Square Head bit.




A5WALO010



Make sure the front and rear edge of part F is aligned properly with the lower cabinet.

This will be carefully balanced until the top plate is attached.



Locate part A (wood platform removed from small pallet)

Affix to part B as shown with 4 of black #8 X 1¼" Bugle screws using a # 2 Square Head bit.  
(2 per side)



A5WALO010




Move the middle cabinet into position close to rear assembled cabinet.  
Snip plastic wire ties holding cables carefully to avoid cutting wires.

On the left side - uncoil the USB cable - push this through the middle cabinet section and through the front cabinet when the time comes and plug into the motherboard.



Plug both pink connectors (CE15011 to CE15012 and CE15015 to CE15016), HDMI connectors, and yellow connectors (CE15018 to CE15019) together.



On the right side, plug the orange connectors (CE15021 to CE15022) and power cords together.



# CONNECT 4 HOOPS HD SETUP

Position the middle cabinet up tight against the rear cabinet.

Locate the 2 of the middle connector plates. Part 2 from box # 1.



Install the plates on the side of the cabinet with 16 of the black 1/4-20 X 1" Phillips head bolts using a # 3 Phillips Head bit. (8 per side) Install bolts loosely, until all are started.



A5BOPH312

**Note:** Use crescent wrench to raise the rear section if cabinet sections do not line up properly.



Tighten all 16 bolts.

## Install Cages:

Position a side cage part 5 (they are interchangeable) along the side of the cabinet with the longer bracket on top.

Using a 6 foot ladder, install 2 of the black 1/4-20 X 1" Phillips head bolts using a # 3 Phillips Head bit on the top rear end of cage.



A5BOPH312




Install 3 of the black #10 screws using a # 2 Square Head bit into the bottom edge of the cage.



A5SCPH152

Repeat the process for the other side cage.



Move the front console into position close to rear assembled cabinet. Snip plastic wire ties holding cables carefully to avoid cutting wires.


On the left side, continue routing the USB cable into the front cabinet and plug into the motherboard.

Plug gold connectors (CE15016 to CE15017), HDMI connectors, and green connectors (CE15019 to CE15020) together.



# CONNECT 4 HOOPS HD SETUP

On the right side, plug the white connectors (CE15022 to CE15023) and power cords together.



Position the front console up tight against the middle cabinet assembly.

Locate the 2 of the middle connector plates. Part 3 from box # 1.



Install the plates on the side of the cabinet with 16 of the black 1/4-20 X 1" Phillips head bolts using a # 3 Phillips Head bit. (8 per side)

Install bolts loosely, until all are started.



**Note:** Use crescent wrench to raise the rear section if cabinet sections do not line up properly.

Tighten all 16 bolts.

## Install 3 top roof boards:

Locate the 3 Game Roof Boards (Part G) from box # 1.

These can be brought inside the cabinet and positioned from the inside.

Place each on top of game in the cage channel.  
Ensure the T-nuts are facing upward.  
Align holes in wood with holes in metal cage.



Install 4 of the black 1/4-20 X 1" Phillips head bolts using a # 3 Phillips Head bit into each roof board. (2 in each side, 12 total)





# CONNECT 4 HOOPS HD SETUP

## Build Marquee:

Locate parts H, K, L, and the 2 J's from box # 2.

Lay out the boards on the floor as shown:

(The 2 J pieces are interchangeable.)





Using 2 people, one at each end, position the 3 boards (H, L, & K) as shown and assembly following these guidelines:

When assembling L to K - this left side has an extra power connector going to the top of the game:

Plug the 4 pin Molex connector together.

Route the extra power cable through the hole in the top panel L





# CONNECT 4 HOOPS HD SETUP

Carefully stuff the wire light cables inside the gap of the white cover as the notches are lined up and wood is slid together.

This will provide the corner with a nice, clean finish.

Install corners (J) on assembly with 8 of black 10 X 5/8" screws using a # 2 Square Head bit.

The corners are interchangeable and have notches to help in positioning.



Install 2 more of black 10 X 5/8" screws into the bracket on other side of top wood piece using a # 2 Square Head bit.




Repeat this process for the other corner using the other J piece.

Remove the circular marquee from Box # 2.

## Install circular marquee:

Using 2 people, stand the assembly upright on the floor in front of the game.

Be sure the white plastic is facing out into the game room.  
Ensure the red artwork is on the left side.



## Marquee Mounting Options:

The marquee can either be mounted under the rood of the cabinet, or on top.

If you have at least 9 inches of clearance above your game (total of 117"), the round marquee may be installed on top of the game. This is a matter of personal preference:

### Standard mounting under the roof



### Optional mounting on top



# CONNECT 4 HOOPS HD SETUP

## Option A: Standard mounting under the roof




Remove the circular marquee from Box # 2.


### Install circular marquee:

Using 2 people, stand the assembly upright on the floor in front of the game.

Be sure the white plastic is facing out into the game room.  
Ensure the red artwork is on the left side.




Using 3 people, lift the circular marquee up into position on top of the front section.



Push the power cable from marquee into the hole in top wood.

Secure marquee onto assembly using 8 of 1/4-20 X 1 1/2" Phillips head bolts using a # 3 Phillips Head bit into each support bracket.

(4 per side) Place a 1/4" split washer onto the bolt then insert into the metal support bracket.




A5BOPH320




A5WASI020

Place bracket up against the wood, bolt/split washer through holes.

push



Place a 1/4" flat washer and 1/4" nut on top of wood and tighten using a 7/16" wrench.



A5WAFL060



A5NULO050

Repeat process for other support bracket.




# CONNECT 4 HOOPS HD SETUP

## Option B: Mounting on top of game



The brackets will have to be flipped on the marquee.  
Remove the circular marquee from Box # 2. Lay on floor as shown.

On yellow side - Remove the 4 bolts using a Phillips screwdriver.  
Rotate the bracket 180 degrees and re-install, from this to this.



On red side - Remove the 4 bolts using a Phillips screwdriver.  
Pull the cable from the center of the support, it will be moved to under the bracket, against the marquee.  
Remove the support bracket.



Route wires in the channel so the wires do not get pinched. as shown.  
Rotate the bracket 180 degrees and re-install.



### Install circular marquee:

Using 2 people, stand the assembly upright on the floor in front of the game.

Be sure the white plastic is facing out into the game room.  
Ensure the red artwork is in on the left side.

Using 3 people, lift the circular marquee up into position on top of the front section.

Secure marquee onto assembly using 8 of 1/4-20 X 1 1/2" Phillips head bolts using a # 3 Phillips Head bit into each support bracket.  
(4 per side)

Place a bolt with flat washer up into the wood, through metal bracket,



A5BOPH320



A5WAFL060

Secure with a 1/4" split washer and 1/4" nut  
bolt and  
tighten using a 7/16" wrench.

Repeat process for other support bracket.




A5WASI020



A5NULO050

onto



# CONNECT 4 HOOPS HD SETUP

## Continuing Assembly with either option:

Plug in the marquee power cable to the cable on the top left side of assembly.

There is also a coiled cable there that will be used later in the installation.




Using 3 people, carefully lift the marquee on top of the front cabinet.

The left side will have 2 cables that will feed down into the lower front cabinet.

The right side will have 1 cable that will feed down into the lower front cabinet.

As the marquee assembly is lifted up, feed these cables down into the holes on both left and right sides.



Locate the 2 of metal front connector plates. Part 4 from box # 2.



Install the plates on both sides of the cabinet with 8 of the black 1/4-20 X 1 Phillips head bolts using a # 3 Phillips Head bit.  
(4 per side)



Install 16 of 1 1/4" black bugle screws using a # 2 Square Head bit to secure the white and black plastic to the lower cabinet on both sides.  
(8 per side)



A5WALO010






# CONNECT 4 HOOPS HD SETUP

Using a 6 foot ladder, install 2 of the black ¼-20 X 1 Phillips head bolts using a # 3 Phillips Head bit on the top front end of cage. This will secure the cage to the front marquee.


Repeat on other side.




Locate the coiled cable in the front left roof of the cabinet.  
Snip plastic wire ties holding cables carefully to avoid cutting wires.  
Stretch this cable to the rear left corner of the game to plug into the rear lights cable part # AALB15044



Open the left red coin door and connect the 2 cables from marquee:  
2 pin connector CE15005 to CE15006  
4 pin connector CE15039 to CE15007



Open the right yellow coin door and connect the 1 cable from marquee:  
4 pin connector CE15039 to CE15009




Locate the Clear Acrylic ball guard from box # 1.  
Remove the protective paper from both sides of the Acrylic plexi.

The flat edge bottom of the plexi will fit into the groove between the white plastic and wood lip.

Slide acrylic plexi down in between the black plastic pieces into this groove.


The plexi shield is held in place by gravity.



## Power on game:

Open the front middle door, and ensure the USB cable from the rear controller board is plugged into any of the USB slots on the motherboard.

Turn on rocker switch on the power strip.



The game is now set up and ready for play!

Enter menu to adjust settings to your location specific price per play and ticket payout.

# HOW TO PLAY


Choose a side and insert your credits;  
6 balls will appear in the ball area.  
Wait for a partner to join, or shoot a ball  
to play solo!



Shoot when it is your turn.



Be the first to align 4 of your basketballs  
horizontally, vertically, or diagonally to  
win!



Collect your tickets once you Connect 4!



# MAIN MENU FUNCTIONS

The Menu and Menu Select buttons are located inside the center lower front door.

Hold the MENU button down for 1 second to open the main menu on the display.

Press MENU to scroll through the options, and MENU SELECT to change the settings.

Default settings are highlighted in yellow below.



MAIN MENU		
CLEAR CREDITS / TICKETS	Press the Menu Select button 3 times to clear any accumulated credits and tickets.	
VOLUME & ATTRACT SETTINGS	Press the Menu Select button to enter the Volume & Attract Settings Menu	
GAME SETTINGS	Press the Menu Select button to enter the Game Settings Menu	
PAYOUT SETTINGS	Press the Menu Select button to enter the Payout Settings Menu	
STATISTICS	Press the Menu Select button to enter the Statistics Menu	
DIAGNOSTICS	OFF	ON Set to "ON" and exit menu to enter Diagnostic Menu
RESET FACTORY DEFAULTS	Press Menu Select button 3 times to Reset Factory Defaults	
MUTE	OFF	ON Set to "ON" and exit menu to Mute entire game.
EXIT MENU	Press the Menu Select button to exit menu.	

Software version is shown on the display as you enter the menu.

**PC Version: 2.0.7d**  
**Red Door: 1.5**

**Aux Version: 2.5**  
**Yellow Door: 1.5**

If one shows "Not Found" then the circuit board is not communicating to motherboard.

**Yellow Door: Not Found**


# VOLUME & ATTRACT SETTINGS

Scroll through the options by pressing the “MENU” button.

Change selection with the “SELECT” button.

Scroll to “BACK” and press the “SELECT” button to go back to the main menu.

Default settings are highlighted in yellow below.



## GAME VOLUME

Change selection with the “SELECT” Button. Default settings are highlighted in yellow below.

0	1	2	3	4	5	6	7	8	9	10
---	---	---	---	---	---	---	---	---	---	----

Sets the game’s playing volume. “0” means the volume is off.

## ATTRACT VOLUME

Change selection with the “SELECT” Button. Default settings are highlighted in yellow below.

0	1	2	3	4	5	6	7	8	9	10
---	---	---	---	---	---	---	---	---	---	----

Sets the volume level of the attract loop when the game is not being played.  
“0” means the volume is off.

## ATTRACT TIMING

Change selection with the “SELECT” Button. Default settings are highlighted in yellow below.

1	2	3	4	5	6	7	8	9	10
---	---	---	---	---	---	---	---	---	----

Sets the time in minutes between attract sound cycles.




# GAME SETTINGS

Scroll through the options by pressing the “MENU” button.

Change selection with the “SELECT” button.

Scroll to “BACK” and press the “SELECT” button to go back to the main menu.

Default settings are highlighted in yellow below.



## GAME MODE / PAYMENT

<b>NORMAL / TICKETS</b>	<b>NORMAL / POINTS</b>	<b>NORMAL / COUPONS</b>	<b>AMUSEMENT ONLY</b>	<b>SHOW MODE</b>
-------------------------	------------------------	-------------------------	-----------------------	------------------

“NORMAL / TICKETS” means the game will pay out tickets, and show the word “TICKETS” on screen.

“NORMAL / POINTS” means the game will pay out tickets, and show the word “POINTS” on screen.

“NORMAL / COUPONS” means the game will pay out tickets, and show the word “COUPONS” on screen.

“AMUSEMENT ONLY” means the game will not pay out tickets.

“SHOW MODE” means the game will not pay out tickets and will only allow 1 credit at a time.

## TURN TIMEOUT

<b>NO</b>	<b>2</b>	<b>4</b>	<b>6</b>	<b>8</b>	<b>10</b>	<b>12</b>	<b>....</b>	<b>34</b>	<b>36</b>	<b>38</b>
-----------	----------	----------	----------	----------	-----------	-----------	-------------	-----------	-----------	-----------

Sets the time in seconds that a player will forfeit their turn if a basket is not scored.

“NO TIMEOUT” means the turn will end only with a basket scored.

## GAME TIMEOUT

<b>NO</b>	<b>30</b>	<b>60</b>	<b>90</b>	<b>120</b>	<b>150</b>	<b>180</b>	<b>....</b>	<b>240</b>	<b>270</b>	<b>300</b>
-----------	-----------	-----------	-----------	------------	------------	------------	-------------	------------	------------	------------

Sets the time in seconds that the game will end if a basket is not scored.

“NO TIMEOUT” means the game will never end until the game is completed by the player.

## FULL COLUMN SHOOT AGAIN

<b>DISABLED</b>	<b>ENABLED</b>
-----------------	----------------

“DISABLED” means the game will change to next player if a full column is scored.

“ENABLED” means the game will allow the player to shoot again if a full column is scored.

## AI DIFFICULTY

<b>PLAYER PICKS</b>	<b>EASY</b>	<b>MEDIUM</b>	<b>HARD</b>
---------------------	-------------	---------------	-------------

“PLAYER PICKS” means the player will pick computer difficulty (Either easy and hard) for 1 player game. Game will wait indefinitely for 2nd player to join.

Other options are hard coded with our estimate of computer difficulty for 1 player game.

Game will wait 10 seconds for 2nd player to join before starting the 1 player game.

# PAYOUT SETTINGS

Scroll through the options by pressing the “MENU” button.

Change selection with the “SELECT” button.

Scroll to “BACK” and press the “SELECT” button to go back to the main menu.

Default settings are highlighted in yellow below.

PAYOUT	
Credits:	1
Swipe Prompt:	Disabled
Paper Ticket Ratio 2-to-1:	Disabled
Winner Tickets:	110
Loser Tickets:	30
Fixed Tickets:	Disabled
BACK	

## CREDITS

0	1	2	3	4	5	6	7	8	9	10
---	---	---	---	---	---	---	---	---	---	----

Sets the amount of credit pulses needed to start a game. “0” will be free play.

## SWIPE PROMPT

DISABLED

ENABLED

“ENABLED” will show “Swipe Card to Play” verbiage on the screen.

## PAPER TICKETS RATIO 2:1

DISABLED

ENABLED

“ENABLED” will pay out 1 physical ticket for every 2 tickets won.

## WINNER TICKETS

10	20	30	40	50	60	70	80	90	100	110	120	130	....	290	300	310
----	----	----	----	----	----	----	----	----	-----	-----	-----	-----	------	-----	-----	-----

Sets the amount of tickets the winner will receive.

See payout table on next page for recommended settings for average tickets per game.

## LOSER TICKETS

10	20	30	40	50	60	70	80	90	100	110	120	130	....	290	300	310
----	----	----	----	----	----	----	----	----	-----	-----	-----	-----	------	-----	-----	-----

Sets the amount of tickets a non-winner will receive.

See payout table on next page for recommended settings for average tickets per game.

## FIXED TICKETS

DISABLED

ENABLED

“ENABLED” will pay out the same amount of tickets for every game.

# TICKET PATTERNS

WINNER TICKETS	LOSER TICKETS	AVERAGE TICKETS PER GAME	PRICE PER PLAY
20	10	14-16	\$.50 PER PLAY
50	20	34-36	\$1.00 PER PLAY
100	20	48-52	\$1.50 PER PLAY
110	30	68-72	\$2.00 PER PLAY
140	40	88-92	\$2.50 PER PLAY
160	50	100-110	\$3.00 PER PLAY

These are estimates of Average Tickets per Game using the shown ticket values for game winner and game loser.

Change ticket values in the "Payout Settings" menu to change your individual payout percentages.

# STATISTICS

Scroll through the options by pressing the "MENU" button.

Change selection with the "SELECT" button.

Scroll to "BACK" and press the "SELECT" button to go back to the main menu.

Default settings are highlighted in yellow below.

STATISTICS	
Total Red Games:	0
Total Yellow Games:	0
Total Red Tickets:	0
Total Yellow Tickets:	0
Reset Statistics:	cleared
BACK	

## TOTAL RED GAMES

Shows the total number of Red (left side) games played.

## TOTAL YELLOW GAMES

Shows the total number of Yellow (right side) games played.

## TOTAL RED TICKETS

Shows the total number of Red (left side) tickets dispensed.

## TOTAL YELLOW TICKETS

Shows the total number of Yellow (right side) tickets dispensed.

## RESET STATISTICS

Press the "SELECT" button 3 times to reset statistics.


# DIAGNOSTIC MENU

The Diagnostic Menu can be entered by selecting ON in the Main Menu, and then exiting the menu.

The ball gate motor will cycle open, and this screen will appear:

The top column will show hoops scored.

Diagnostic window will show:  
Credits switch activated  
Ticket notch activated  
Input changes



Press the Menu Button to exit diagnostics and return to the main menu.



# CARD SWIPE SYSTEM INSTALLATION


The Connect 4 Hoops game is pre-wired with a UCL (Universal Card Link) connector to accept Card Swipe systems from many different manufactures.

Please follow these instructions to make full use of this capability.

## Option #1:


Card swipe systems may come with a standard 9 pin Molex connector. This is the UCL connector.

Simply plug this connector into your card swipe reader.



## Option #2:

If your card swipe systems does not have a standard 9 pin Molex connector, then you will have to splice wires into the AACE15014 & AACE15015 harness.



## Notes:

- 1.) Many card swipe systems have a voltage threshold that can be adjusted in the card swipe menu. Please set this "Game Drive Threshold" to 2 Volts.
- 2.) There are ticket dispenser extension cables located in the left side coin door if needed.

## Menu Changes

Enter menu, Go to "Game Settings" Menu






Set "Game Mode/ Payment" to desired option

Go to "Payout Settings" Menu

Change "Credits" to 1


Change "Swipe Prompt" to "Enabled"

# CIRCUIT BOARD LAYOUT




## WIRING DIAGRAM

**LEFT SIDE (RED) : TICKET DISPENSER, MENU  
BUTTONS, METERS, DBA AND COIN MECH**




## WIRING DIAGRAM

**RIGHT SIDE (YELLOW) : TICKET DISPENSER,  
DBA AND COIN MECH**






# LED LIGHTING WIRING DIAGRAM




# LED LIGHTING WIRING DIAGRAM




# WIRING DIAGRAM

## BALL GATE MOTOR, SENSOR AND HOOP SENSORS




# COMMUNICATION WIRING DIAGRAM






# 12 V POWER SUPPLY & SOUND WIRING DIAGRAM



Note: Later games may have different colored sockets. The connections are the same.


# AC POWER IN WIRING DIAGRAM





# TROUBLESHOOTING GUIDE

## Troubleshooting Strategy

Use common sense and a systematic method of troubleshooting to determine the exact problem, probable cause and remedy. Use the process of elimination to find the faulty component. Always check for the simple and obvious causes first such as unplugged, loose or broken wires and bad sensors, bent, pinched, stuck or jammed components.

Troubleshooting Chart		
Problem	Probable Cause	Remedy
<b>No power to the game</b> <b>No lights on at all</b>	Unplugged. Circuit breaker tripped. Line Filter Faulty. Power strip faulty. Disconnected, loose or broken wires.	Check wall outlet. Reset power strip breaker switch or building circuit breaker. Replace Line Filter (Part # A5FI9010) Change plug position, replace power strip if a section does not work. Part # A5OU5000 Refer to wiring diagram. Check connections and reseal cables from line filter to outlet strip. Cables # AACE15042, AACE15022, and AACE15043
<b>Monitor is on</b> <b>But everything else off</b> <b>(Power Supply not ON)</b>	Power supply unplugged. Rocker Switch. Power supply shutting down because of 12 V overload. Faulty power supply. Faulty Power Dist Board	Insure power supply is plugged into power strip Make sure rocker switch is set ON.  See power supply diagnostics to isolate bad component. A bad motor or 12 volt short would cause this. See Power Supply Diagnostic below. Replace Power Distribution Board (AACB5156)
<b>Dollar Bill Acceptor not functioning</b> Ensure Bill Acceptor is set to "Always Enable" <b>Important : Only 12 Volt DC DBA is to be installed.</b> Model # AE 2454 U5E Part # A5AC9101	Check for power to Bill Acceptor. Dirt or debris in acceptor slot. Pinched, broken, or disconnected wiring. Bill acceptor problem. Part # A5AC9101	Acceptor should cycle stacker at game power up. If not, check cable connections. Refer to "How to Clean Bill Acceptor" Or clean with bill reader cleaning card. (A5CC9000) Check wiring from bill acceptor to I/O Aux Board. (AACE15001 & AACE15002) Repair or replace wiring harness. Make sure wires are secure in connectors. Refer to troubleshooting section of dollar bill acceptor manual included with this game or the diagnostics label of the back of the unit.
<b>Meters does not work</b> Game meter will click at the end of the game. Ticket meter will click as tickets come out of game and notch is "seen" by dispenser.	Ensure correct number of tickets are being dispensed Disconnected, loose or broken wires. Faulty counter.	Check ticket values in menu. Refer to Tickets not dispensing troubleshooting section. Refer to wiring diagram. Check connections and reseal cables from meters to left I/O Aux Board Cables # AACE15010 and AACO1020 Replace counter. AACO1020.

# TROUBLESHOOTING GUIDE


Problem	Probable Cause	Remedy
<b>Game not coining up</b> Enter Diagnostic Mode (Turn diagnostics on, then exit menu) to see if Credits Increment when coin is inserted. 	Look for communication and power on the I/O Aux Board for that player.  Ensure game makes sound when coin switch is triggered.  Game set to large amount of credits per game.  If Coin Input stays ON	Refer to "I/O Aux Board Issue" diagnostic section.   Check coin switches—both should be wired normally open. If one switch is "closed" the other will not work either. Check wiring to I/O Aux Board. (AACBL4A-DOORA, AACE15013 or AACE15014)  Check Game Setup Menu. Ensure Credits is set to proper value.  Ensure only 5 volts on coin switch green and black wires. I/O Aux board may be faulty. Swap I/O Aux board with other player side, making sure to change dipswitch settings. (Left side both off, Right side dip 1 is on, 2 is off)
<b>No Sound</b>  Motherboard creates sound, the Audio Amplifier boards amplifies it.	Volume set to mute in menu or game volume/attract volume set to zero.  Disconnected, loose or broken wires.   Verify 12 Volts DC to Audio Amplifier Boards  Faulty speaker.	Enter Main Menu and verify: Game Volume & Attract Volume is not zero. Mute is set to OFF  Refer to wiring diagram. Check connections and reseal audio cable from motherboard to speakers. Cables # A5CEAU010, A5CE2300, AACE15008, AACE8811  Unplug audio cable (A5CEAU010) from motherboard, plug into MP3 player or phone and see if music is amplified and comes out of speaker. If Yes - then motherboard is faulty. If No - then cable or amplifier board is faulty Replace speaker. AACE8811
<b>I/O Aux Board Issue</b>  One side of the game does not coin up, and has no other functions.  Red and Yellow LEDs Green Power LED	Green power LED should be flashing. One blink for left side, 2 blinks for right side)   Red and Yellow LED's should be flashing.  Faulty I/O Aux Board.	If it is off, then check 12 & 5 Volts DC coming into board on cable AACE15013 or AACE15014 from Power Distribution Board. If solid on, then it is not communicating with the motherboard. Check A5CBL5900 USB cable. Swap cables with other side.  If they are off, it is not communicating with the motherboard. Check A5CBL5900 USB cable. Swap cables with other side.  Swap I/O Aux board with other player side, making sure to change dipswitch settings. (Left side both off, Right side dip 1 is on, 2 is off) Replace if needed. Part # AACB9604






# TROUBLESHOOTING GUIDE

Problem	Probable Cause	Remedy
<b>LED white rear cabinet lighting above hoops not working</b>	LED's receive 12 Volts DC from power supply through The Power Distribution Board.  Faulty LED light.	Check for proper connection from power supply to Power Distribution Board.  Refer to wiring diagram. Check connections and reseal cables from Power Distribution Board to LED lights. Cables # AACE15006, AACE15005, AALB15044, and AALB15045.  Light strips are wired in series. Swap the 2 light strips to identify a faulty LED strip. Replace as needed. Part # AALB15044 or AALB15045
<b>LED white front panel light not working</b>	LED's receive 12 Volts DC from power supply through The Power Distribution Board.  Faulty LED light.	Check for proper connection from power supply to Power Distribution Board.  Refer to wiring diagram. Check connections and reseal cable from Power Distribution Board to LED lights. Cables # AACE15003, and AALB15043  Replace Panel Stick Light. Part # AALB15043
<b>Upper marquee LED's not working</b>	LED's receive 12 Volts DC from power supply through The Power Distribution Board.  Faulty LED light.	Check for proper connection from power supply to Power Distribution Board.  Refer to wiring diagram. Check connections and reseal cables from Power Distribution Board to LED lights. Cables # AACE15006, AACE15005, and AACE10045  Light strips are wired in series. Swap the 2 light strips to identify a faulty LED strip. Replace as needed. Part # AALB15047 or AALB15048
<b>One of the left side, red colored LED strips not working</b>  LED's receive 12 Volts DC from Control Board in the rear of the game.  Refer to "How to Access Rear Control Board"	If all colored cabinet lights are not functioning, check power into the Control Board from the Power Distribution Board.  If single LED strip is out, check cable. LED's are wired in series. Refer to wiring diagram.  Faulty LED	Refer to wiring diagram. Check connections and reseal cables from Power Distribution Board in the front of the cabinet to Control Board in the back. Cables # AACE15017, AACE15016, and AACE15015  Check for 12 volts coming from Power Distribution Board in the rear of the cabinet on red and black wires. If no 12 volts DC, ensure 12 volts is coming into board on cable # AACE15018. If voltage is present - replace Control Board part # AACB10000  Refer to wiring diagram. Cables # AACE15018, AACE15019, AACE15020, AALB15042, AACE15007, AACE15040, AACE15039, and AACE15041  Swap LED connector from one socket to the other to verify. Replace LED as needed.


# TROUBLESHOOTING GUIDE

Problem	Probable Cause	Remedy
<p><b>One of the right side, yellow colored LED strips not working</b></p> <p>LED's receive 12 Volts DC from Control Board in the rear of the game.</p> <p>Refer to "How to Access Rear Control Board"</p>	<p>If all colored cabinet lights are not functioning, check power into the Control Board from the Power Distribution Board.</p> <p>If single LED strip is out, check cable. LED's are wired in series. Refer to wiring diagram.</p> <p>Faulty LED</p>	<p>Refer to wiring diagram. Check connections and reseal cables from Power Distribution Board in the front of the cabinet to Control Board in the back. Cables # AACE15017, AACE15016, and AACE15015</p> <p>Check for 12 volts coming from Power Distribution Board in the rear of the cabinet on red and black wires. If no 12 volts DC, ensure 12 volts is coming into board on cable # AACE15018. If voltage is present - replace Control Board part # AACB10000</p> <p>Refer to wiring diagram. Cables # AACE15018, AACE15019, AACE15020, AALB15042, AACE15007, AACE15040, AACE15039, and AACE15041</p> <p>Swap LED connector from one socket to the other to verify. Replace LED as needed.</p>
<p><b>LED color strip under the hoops are not working</b></p> <p>LED's receive voltage from Control Board in the rear of the game.</p>	<p>Ensure Control Board is receiving voltage from Power Distribution Board.</p> <p>Faulty LED</p>	<p>Refer to wiring diagram. Check connections and reseal cables from Power Distribution Board in the front of the cabinet to Control Board in the back. Cables # AACE15017, AACE15016, and AACE15015</p> <p>Refer to wiring diagram. Cables # AACE15000, AALB15000 and A5CB15000</p>
<p><b>Menu Buttons do not work.</b></p>	<p>Swap connectors at the 2 buttons.</p> <p>Pinched, broken, or disconnected wiring</p> <p>I/O Aux board faulty.</p>	<p>Replace button if problem stays with button.(AAPB2700)</p> <p>Inspect crimp to ensure good connection.</p> <p>Check connections from menu buttons to left I/O Aux Board. Check cables (AAPB2700, AACE15010)</p> <p>Swap I/O Aux board with other player side, making sure to change dipswitch settings. (Left side both off, Right side dip 1 is on, 2 is off)</p> <p>Replace I/O Aux Board. Part # AACB9604</p>
<p><b>Low Tickets message on monitor</b></p> 	<p>Tickets are empty in ticket tray</p> <p>Faulty cable. Disconnected, loose or broken wires.</p> <p>Faulty low ticket switch.</p> <p>Faulty I/O Aux Board.</p>	<p>Load tickets into tray. Ensure tickets hold down micro switch wire.</p> <p>Check connectors from low ticket switches to Newgen board. Check for continuity. (AACE10014 or AACE10015)</p> <p>Inspect switch and replace if needed. (AASW200)</p> <p>Swap I/O Aux board with other player side, making sure to change dipswitch settings. (Left side both off, Right side dip 1 is on, 2 is off) Replace I/O Aux Board. Part # AACB9604</p>

# TROUBLESHOOTING GUIDE

Problem	Probable Cause		Remedy
<b>Tickets do not dispense or Wrong amount dispensed.</b>  Check for the correct amount of tickets showing on Monitor	Tickets on monitor does <b>not</b> match tickets coming out of game.	Opto Sensor on ticket dispenser dirty. Faulty ticket dispenser.  Notch on tickets cut too shallow. Faulty cable. Disconnected, loose or broken wires.  Faulty I/O Aux Board.	Blow dust from sensor and clean with isopropyl alcohol. Replace with working dispenser to isolate the problem. (A5TD1) Flip tickets and load upside-down to have large cut notch toward opto sensor. Check connectors from ticket dispensers to I/O Aux board. Check for continuity. Cables AACE15013 or AACE15014 Swap I/O Aux board with other player side, making sure to change dipswitch settings. (Left side both off, Right side dip 1 is on, 2 is off) Replace I/O Aux Board. Part # AACB9604
	Tickets on monitor does match tickets coming out of game.	Settings in Menu are incorrect.	Enter Menu and check certain areas: Game Mode / Payment to Normal/ Tickets Paper ticket ratio 2 to 1 Winner Tickets Loser Tickets - Note: A tie is a loser. Fixed tickets
<b>Monitor not working.</b>  Power down, wait <b>5 minutes</b> and power up again.	Screen shows "No Signal Input"  <b>Note: Monitor must be plugged in for motherboard to boot up.</b>	Monitor HDMI cable unplugged. There are 3 cables that are connected together - A5CORD36, A5CORD37, and A5CORD51 Faulty or loose RAM Large power connector unplugged on motherboard Note: Later games may have different colored sockets. The connections are the same. Small power connector unplugged on motherboard Faulty power supply - Refer to Power Supply diagnostic section Faulty motherboard - Replace faulty board. (AAMB10E-HD) 	
	Screen has nothing at all on power up.	Power cable unplugged from Monitor.  Turn on Monitor. Faulty monitor.	Ensure power is plugged into back of monitor, down to power strip. There are multiple power cords. A5CORD5003, A5CORD1, and A5CORD50 Install batteries in remote control and try using remote control to power on monitor. Replace monitor. (A5MO0065A)
	Error on screen at power up.  Re-Boot game to see if problem still exists.	Display shows "Kernel panic – unable to mount root" Display stuck on "Biostar" 	Faulty or loose RAM, faulty software, faulty motherboard No SATA drive in motherboard. Check for power connector 

# TROUBLESHOOTING GUIDE


Problem	Probable Cause		Remedy
<b>Ball Gate Motor keeps running.</b> <b>Motor will cycle at game power on.</b> <b>Sensor not being seen.</b>  Sensor receives signals through the Control Board in rear of game.	Check for 12 volts to sensor and 5 volt signal return.  Pinched, broken, or disconnected wiring  Faulty Control Board. Refer to "How to Access Rear Control Board"		There should always be 12 volts on the yellow and blue wires. 5 volts on the white and blue wires when blocked and 0 volts when not blocked. Refer to wiring diagram. Check connections sensor to Control Board. Cables AACE15011 & AACE15012 Ensure Control Board is receiving 12 volt power. Refer to wiring diagram. 12 Volts DC should be between yellow and black wires on cables AACE15017, AACE15016, and AACE15015 Replace Control Board if needed. # AACB10000
<b>Ball Gate Motor not working.</b>  <b>Motor will cycle at game power on.</b>	Motor does not turn at power on.  Motor receives power through the Control Board in rear of game.  Refer to "How to Access Rear Control Board"	Check for 12 volts DC at motor.  Faulty cable. Disconnected, loose or broken wires.  Faulty Control Board.	If the motor is receiving power, but not turning, replace the motor. A5MO5154  Check connectors from motor to Control Board. Check for continuity on cables AACE15012 & AACE15011 to Control Board. Ensure Control Board is receiving 12 volt power. Refer to wiring diagram. 12 Volts DC should be between yellow and black wires on cables AACE15017, AACE15016, and AACE15015 Ensure Control Board is receiving USB communication. Refer to wiring diagram. Change USB cables A5CBL5900, A5CORD23, A5CE6601 OR use 1 piece A5CORD40 Replace Control Board if needed. # AACB10000
	Motor turns at power on, but does not stop in correct position.	Mechanical linkage/ spring issue.  Position Sensor is not working correctly.	Check springs on each end of the ball gate. Replace if needed. Part # A5SREX050  Clean sensor. Refer to "Ball Gate Motor keeps running" Replace sensor if needed. AACB5190A
	<b>Ball Gate does not go down all the way.</b>	Loosen the 2 bolts on the motor assembly, and slide bracket with slotted holes to adjust height of ball gate.	



# HOOPS NOT SCORING

All ball sensor boards have 4 emitters and 1 detector on opposite sides of the board. These infrared sensors create a beam which the ball breaks to score a hoop.

Because these are interchangeable, the far left (#1) board can be swapped into a location with a faulty emitter. The far right (#8) board can be swapped into a location with a faulty detector.




## Diagnostic Menu

To Enter the Diagnostic Menu:

Enter Main Menu and scroll down to "Diagnostics:" turn to ON  
Exit Menu

The ball gate motor will cycle open, and this screen will appear:

The top column will show hoops scored.



## How to Access Sensors:

The ball hoop sensors are accessed through the back of the cabinet, or through the middle platform access panel. If the game is up against the wall, carefully climb over the plexi shield (or remove the plexi) and enter the middle section of the game.

Remove the 4 screws (using a # 2 square bit) in the center bottom wood and lift center wood up and place aside.

The sensors are located underneath and behind the monitor.

Remove the 2 of # 2 square bit screws and pull down the sensor.



# POWER SUPPLY DIAGNOSTICS


1.) Verify AC power to game. Check power strip in front door. The rocker switch should be illuminated.



2.) Check connection to power supply.

3.) Ensure Power Supply switch is set to 115V (or 230V)  
(Some model power supplies may not have this)

4.) Ensure Power switch is on.




5.) Ensure fan is turning.

- If power supply fan is turning and there is no 12 Volt out:

Check power supply cables to the Power Distribution Board.

This board takes the power in, and directs it to the different 12 volt loads.



Unplug all power out connectors from the right side of the Power Distribution Board.

Turn on game and if it boots correctly, plug one cable in at a time until the issue is found.

Replace power supply if this board is not receiving 12 volts. (A5PS1013)

- If power supply fan is not turning, then continue to "Verify Power to Motherboard"

## Verify Power to Motherboard

The motherboard will turn on power supply.

If your game has no 12 volts, it may be the motherboard not turning on.

Also - there may be a 12 volt short somewhere in cabinet that is not allowing the power supply to turn on.



**AAMB10E-HD  
Motherboard**

### AAMB10E

Make sure the 4 pin power connector is plugged in.  
(Black, Black, Yellow, Yellow)

As well as 24 pin power in connector.

Note: Later games may have  
different colored sockets.  
The connections are the same.

## Minimize load on power supply and isolate short

Unplug the power supply cables going to the Power Distribution Board.

This will leave the power supply, motherboard, and monitor left plugged in together.

If power supply, motherboard, and monitor now turn on:

Plug in the Power Distribution Board to power supply, but unplug all of the outputs from the board.

Turn on game and verify the 12 volts is good.

Then plug in one component at a time to power supply to locate short.

If power supply still does not power on:

Replace power supply (A5PS1013), or motherboard. (AAMB10E-HD)

# BILL ACCEPTOR DIAGNOSTICS

**Note:** There are many different models and brands of Bill Acceptors that are used on redemption games. Your Bill Acceptor may differ from the unit shown. Standard DBA is MEI # AE2454-U5E Part # A5AC9101

Determine if Bill Acceptor has power:

Turn game ON—The bill acceptor should make noise as stacker cycles and green lights on outside bezel should flash.

If NO power:

Use meter to measure 12 VDC voltage at cable going into Bill Acceptor from front I/O Aux Board

If power is OK:

Clean Bill Acceptor path to make sure there is nothing jamming unit.


Check dipswitch settings on side of acceptor.

**Make sure switch # 8 is OFF for Always Enable**



## ERROR CODES

Count the number of flashes on front bezel of Bill Acceptor and follow on Bill Acceptor chart for repair instructions.



## I/O AUX BOARD PINOUT



<span style="color: yellow;">●</span> = +12V	<span style="color: red;">●</span> = +5V
<span style="color: black;">●</span> = Ground	<span style="color: blue;">●</span> = Output
<span style="color: green;">●</span> = Input	

### Outputs:

Q1 (PD1)	Game Counter
Q2 (PD0)	Tickets Counter
Q3 (PD6)	Coin Lockout
PE6	Ticket Enable

### Inputs:

PD4	Menu Button
PC6	Select Button
PD7	Ticket Notch
PB4	Coin In
PB5	DBA In
D15 (A1)	Low Ticket Switch Input


# HOW TO ACCESS BALL SENSORS

The ball hoop sensors are accessed through the back of the cabinet, or through the middle platform access panel. If the game is up against the wall, carefully climb over the plexi shield (or remove the plexi) and enter the middle section of the game.

Remove the 4 screws (using a # 2 square bit) in the center bottom wood and lift center wood up and place aside.

The sensors are located underneath and behind the monitor.

Remove the 2 of # 2 square bit screws and pull down the sensor.




# HOW TO ACCESS REAR CONTROL BOARD

The control board is accessed through the back of the cabinet, or through the middle platform access panel. If the game is up against the wall, carefully climb over the plexi shield (or remove the plexi) and enter the middle section of the game.

Remove the 4 screws (using a # 2 square bit) in the center bottom wood (as pictured above) and lift center wood up and place aside.

The control board is located in the rear section underneath the cabinet.



# HOW TO ACCESS BALL GATE MOTOR & SENSOR

The ball gate motor and sensor are accessed through the back of the cabinet, or through the middle platform access panel. If the game is up against the wall, carefully climb over the plexi shield (or remove the plexi) and enter the middle section of the game.

Remove the 4 screws (using a # 2 square bit) in the center bottom wood (as pictured above) and lift center wood up and place aside.

**Ball Gate does not go down all the way.**

Loosen the 2 bolts on the motor assembly, and slide bracket with slotted holes to adjust height of ball gate.





# MONITOR DEFAULT SETTINGS



Monitor setting screen shots.  
Model # D65A214-U-A



# HOW TO REPLACE MONITOR

The monitor is protected by tempered glass. The glass will be removed first, then the monitor.

Tools needed:

Phillips bit screwdriver

# 2 Square bit

7/16" Wrench

Remove the plexi shield from game and set aside.


Climb into the middle section of the game.

To remove the front tempered glass:

Remove the 6 Philips screws from top rail.

Remove the left and right sides by removing 4 of # 2 square bit screws on each side.

Carefully remove the tempered glass covering monitor. We recommend having one person inside the cabinet and hand the glass to a person standing outside the cabinet.



Remove the 6 screws in the lower black plastic piece using a Phillips bit.



Slide forward and out the bottom black plastic piece with the rounded design.



Remove the 2 bolts under the bottom edge of the monitor using a 7/16" wrench.




Remove the 6 screws on the top edge of the monitor using a Phillips screwdriver.

Note: The screws are installed at a 45 degree angle.



# HOW TO REPLACE MONITOR

Remove the 2 Phillips screws on each upper left and right corner black plastic piece.



Lift up on monitor to unhook the wood attaching monitor to back frame. Set down to unhook cables.



Remove the cable clamp on HDMI cable on the left side of monitor using # 2 square bit. Disconnect the HDMI cord from the HDMI #1 socket.



Remove the cable clamp on the power cable on the right side of monitor using # 2 square bit. Unplug the power cord from the plug on right side of cabinet.




A wood piece will be attached to monitor as it is removed from the cabinet.  
Carefully remove the monitor. We recommend having one person inside the cabinet and hand the monitor to a person standing outside the cabinet.

The monitor can then be replaced by removing the wood backing and installing it on the new monitor.

As it is re-installed in the cabinet, make sure the wood hooks onto the wood ledge in the cabinet.

Make sure the cable clamps are re-installed to keep the cables up and out of the way of the balls when being played.



# HOW TO MOVE MARQUEE TO TOP OF GAME

If you have at least 9 inches of clearance above your game, the round marquee may be installed on top of the game. This is a matter of personal preference:

## Standard mounting under the roof



## Optional mounting on top



### Tools needed:

7/16" Wrench      Phillips Screwdriver      2 people


### Instructions:

Using 2 people, carefully climb up into the cabinet and remove the 8 nut and bolts attaching the marquee to the game using a Phillips screwdriver and 7/16" wrench.

Unplug the 2 pin connector, and set on the floor.

On yellow side - Remove the 4 bolts using a Phillips screwdriver.

Rotate the bracket 180 degrees and re-install, from this to this.



On red side - Remove the 4 bolts using a Phillips screwdriver.

Pull the cable from the center of the support, it will be moved to under the bracket, against the marquee.

Remove the support bracket.



If there is no channel to route wire, use a spade drill bit to create a channel so the wires do not get pinched.



Route wires as shown.

Rotate the bracket 180 degrees and re-install.



Using 2 people, carefully bring the marquee back up onto the top of the game and re-install the bolts, washers, and nuts. Make sure these are all tightened completely. Plug in the power connector. Installation is complete.

# HOW TO UPDATE SOFTWARE

## New Software Installation:


The hard drive contains all the information about the game: Credits per play, ticket pattern, etc. Be sure to check this information after finishing installing new software.

Turn off game by flipping the power switch on the power strip.

Locate hard drive on motherboard.

Press tab on far side of hard drive and gentle remove from motherboard.

Unplug power supply jumper connector and remove old hard drive from unit.



**AAMB10E-HD  
Motherboard**


Install new hard drive by gently pushing straight onto motherboard until it “clicks”. Turn the game back on by flipping the power switch on the power strip.

Note: Later games may have different colored sockets. The connections are the same.

Note: The I/O boards will automatically be updated by the motherboard software.

# BLANKING PLATES AVAILABLE

A5PL4200 DBA Plate used for Upstacker Bill Acceptor



A5PL9998 Plate used instead of Coin Mechanisms



A5PL8900 Plate used for Bill Validator



A5PL9995 Plate used instead of ticket dispenser





# DIPSWITCH SETTINGS

Dipswitches must be set correctly on the I/O Aux Boards or game will not know which is left or right player.

Turn off game by flipping the power switch on the power strip.  
Set dipswitches as shown:



**Left Side (Red Player)**

Both switches 1 and 2 should be set to OFF




**Right Side (Yellow Player)**

Set switch 1 to ON , Set switch 2 to OFF


There are also a 8 dip bank of dipswitches on the I/O Aux Boards.

SWITCH	DESCRIPTION	ON	OFF
1	<b>SHOW GAME</b> Does not dispense tickets and clears all accumulated credits if ON		X
2	<b>AMUSEMENT ONLY</b> Does not dispense tickets if ON		X
3	<b>NJ LOCKOUT</b> Saves tickets owed and unused credits after a power loss if ON		X
4	<b>1/2 TICKET PAYOUT</b> Dispenses 1/2 the amount of tickets as shown on screen. It will round up odd amounts of tickets if ON		X
5	<b>DISABLES LOW TICKET INPUT</b> Disables the low ticket message on screen if ON. This option should be enabled when using a card swipe system	X	
6	<b>NOT USED</b>		
7	<b>NOT USED</b>		
8	<b>NOT USED</b>		






## BALL GATE EXPLODED VIEW




<b>Part #</b>	<b>Description</b>	A5HKSQ020	S Hook	A5SCSQ001	#6 X 3/4" Screw
A5BOCG065	10-24 x 1 1/4" Bolt	A5ME15006	Ball Gate	A5SREX050	3/8" X 6" Spring
A5BOEY010	10-24 Eye Bolt	A5NULO040	10-24 Nut	W5HG1030	23" Hinge
A5BRZN030	1" X 1" X 2" Bracket	A5SCPH190	10-24 X 1/2" Screw		



Part #	Description				
A5BOHH030	10-32 X 3/4" Bolt	A5MUNY010	Sticky Tab	A5SENY170	1/4" X 1/4" Spacer
A5BOPH030	4-40 X 1/2" Bolt	A5NUNY020	4-40 Nylon Hex Nut	A5SFNY010	#4 X 1/4" Standoff
A5CB5190A	Sensor	A5PICV032	1/4 X 1 5/8" Clevis Pin	A5TWNV010	4" Wire Tie
A5ME1727	Motor Bracket	A5PICZ005	3/32" X 1/2" Cotter Pin	A5WAET020	#10 Tooth Lock Washer
A5MO5154	Motor	A5PIRO015	3/16" X 1 1/4" Roll Pin	WACA15110	Black HDPE 1/2" Thick

# BALL GATE EXPLODED VIEW



Part #	Description		
A5BOHH050	25-20 x 1 1/4" Bolt	A5SENY170	1/4 " X 1/4" Nylon Spacer
A5BOPH190	10-24 X 1 3/4" Bolt	A5SLLO020	1/4" Bore Shaft Collar, 3/32" Allen
A5ME1727	Motor Bracket	A5SP10000	7/16" X 2 3/4" Spring
A5MO5154	Motor	A5WAFL040	#10 Zinc Flat Washer
A5NUNY040	8-32 Hex Nylon Nut	A5WAFL060	1/4" Flat Washer
A5NUTE020	1/4 -20 T Nut	A5WASI020	1/4" Split Washer
A5PICV032	1/4 X 1 5/8" Clevis Pin	WAC4H0001	Wood for Ball Gate
A5PICV045	1/4 X 2 3/8" Clevis Pin	WARR0001-C4HP	Black HDPE 1/4" Thick Arms
		WARR0002-C4HP	Black HDPE 1/2" Thick Pivots

# PARTS LIST

PART #	DESCRIPTION	PART #	DESCRIPTION
94639A207	Spacer, Nylon 1/4"Od,5/16"Lg,#4	A5DE15020	Decal, Left Red Shelf Decal
A5BA15000	Basketball W/Logo, Mini, Size 3	A5DE15014-1	Decal, Cab Side Left Bottom Panel
AABK1013	Bracket, Pushbutton/Counters	A5DE15014-2	Decal, Cab Side Left Top Panel
A5BK9999	Bracket, Power Supply Mounting	A5DE15021	Decal, Right Yellow Shelf Decal
A5CB2050	Coin Box, Black Plastic Cash Box	A5DE15015-1	Decal, Cab Side Right Bottom Panel
A5FI9010	Filter, F1700ca06, Inline	A5DE15015-2	Decal, Cab Side Right Top Panel
A5HA1200	Handle, Cash Box, White Plastic	A5DE15016	Decal, Front Cover, Plexi PETG
A5HO1003	Holder For Light Bars	A5DE15019	Decal, Marquee, Polycarb
A5KIT-HOOPSHD	Hardware Kit, C4 Hoops HD	A5DE10021	Decal, Caution, Ball Trough
A5LK2001	Lock, Cash Box, A05/E00 Key Code	A5ME10001	Metal, Top Lock Bracket
A5LK5002	Lock, 7/8", H95 Key Code	A5ME10008	Metal, Center Side Guard
A5LV10000	Levelers, C4 Hoops Cabinet	A5ME10016	Metal, Right Coin Guide
A5OU5000	Outlet Strip, Four Positions	A5ME10017	Metal, Left Coin Guide
A5PL4200	Plate, Upstacker Bill Acceptor Plate	A5ME10018	Metal, Cage Panel Bracket
A5PL8900	Plate, Bill Validator Blanking Plate	AAME15019	Metal, Side Cages
A5SLL0020	1/4" Bore, Shaft Collar 3/32" Allen	A5ME15000	Metal, Marquee Mount
A5SP10000	Spring, Extension, 7/16 X 2-3/4	A5ME15001	Metal, Top Front Cab. Connector Plate
A5SREX050	Spring,6",3/8"Od,.041"	A5ME15002	Metal, Front Side Rail
AASW200	Low Ticket Switch	A5ME15003	Metal, Front Rail
A5TG15000	Tempered Glass, 3/16" X 33.56" X 58.38"	A5ME15004	Metal, Side Cab. Connector
A5VF4604	Vacuum Form, Cup Holder	A5ME15005	Metal, New Tray Insert
AACO1020	Counter Assy	A5ME15006	Metal, Lift Gate
W5HG1025	Hinge,16",Double Bend	A5ME15007	Metal, Back Side Rail
W5HG1030	Hinge,23",Single Bend	A5ME15008	Metal, Window Rail Mount
W5HG1040	Hinge,8-3/8"Single Bend	A5ME15009	Metal, Light Bracket
W5HG1065	Hinge, 5-75, Single Bend	A5ME15010	Metal, Back Cab. Top Connector
W5KE5000	Keeper, Lock	A5ME15011	Metal, Top Rail
W5TM4000	T-Mold,7/8"Black	A5ME1727	Metal, Motor Bracket
A5DE15000	Decal, Speaker Panel, Polycarb	A5ME4179	Metal, Ticket Tray Bracket
A5DE15001	Decal, Backboard, Polycarb	A5CBL4A-DOOR	Cable, Double Coin Door
A5DE15002	Decal, Cabinet Front	A5CBL5900	Cable, USB, Male A To Male Micro
A5DE15003	Decal, Left Ticket Door Decal	A5CE2300	Cable, Audio Isolator
A5DE15004	Decal, Right Ticket Door Decal	A5CE6601	CABLE,USB,6',EXTENSION,Black
A5DE15005	Decal, Cash Box Door Decal	A5CEAU010	Cable, Audio Stereo,3.5mm
A5DE15006	Decal, Mech Door Left, Red	A5CORD1	Cord,Power,10'
A5DE15007	Decal, Mech Door Right, Yellow	A5CORD23	Cord,10' USB,A Male To A Female
A5DE15008	Decal, Left Red Platform With Caution	A5CORD36	Cord, 8' HDMI To HDMI
A5DE15009	Decal, Right Yellow Platform W Caution	A5CORD37	Cord, 15' Male To Female HDMI
A5DE15010	Decal, Cab Side Top Left	A5CORD50	Cord, Power, 3ft
A5DE15011	Decal, Cab Side Bottom Left	A5CORD51	Cord, HDMI, 6ft, Male To Female
A5DE15012	Decal, Cab Side Top Right	A5CORD5-A	Cord, Ac Computer Cord
A5DE15013	Decal, Cab Side Bottom Right	AALB15000	Cable Assy, 1st Hoop Addressable Board

# PARTS LIST

PART #	DESCRIPTION	PART #	DESCRIPTION
A5CB15000	Hoop Light Board, not 1st	AACE15037	Cable Assy,Cb9600 To Power Distribution
AACE15000	Cable Assy, Hoop Addressable Light Power	AACE15038	Cable Assy, Power Distribution To Boards
AACE15001	Cable Assy, Right DbA	AACE15039	Cable Assy, Side Rail Led
AACE15002	Cable Assy, Left DbA	AACE15040	Cable Assy, Player Panel Led
AACE15003	Cable Assy, Power To Panel Stick Light	AACE15041	Cable Assy, Top Player Led
AACE15005	Cable Assy, Top Light Pwr Side Jumper	AALB15042	Cable Assy, Small Panel Lights
AACE15006	Cable Assy, Top Light Pwr From Board	AALB15043	Cable Assy, Underside Panel Light
AACE15007	Cable Assy, Red Light Power From Panel	AALB15044	Cable Assy, Back Cabinet Stick Light
AACE15008	Cable Assy, Speakers	AALB15045	Cable Assy, Back Cabinet Stick Light
AACE15009	Cable Assy, Yellow Light Pwr Jmp From Panel	AACE1710	Cable, Door Ground Cable
AACE15010	Cable Assy, Menu/Counters	AACE1715	Cable, Door Ground Cable
AACE15011	Cable Assy, Lifter Sensor From Board	A5MO0065A	TV, 65" 4k Ultra HD
AACE15012	Cable Assy, Lifter Sensor To Sensor	A5MO5154	Motor, Ball Gate,10 Rpm
AACE15013	Cable Assy, Right Coin Door/Ticket Disp	A5PS1013	Power Supply, EVGA 500
AACE15014	Cable Assy, Left Coin Door/Ticket Disp	A5TD1	Ticket Dispenser, Entropy
AACE15015	Cable Assy, Back Door Board To Center	AACE8811	Cable Assy, Speaker
AACE15016	Cable Assy, Center Cable For Door Board Pwr	AAPB2700	Push Button Assembly
AACE15017	Cable Assy, Back Door Board Pwr From Front	A5CB10001	PCB, Hoop Sensor, 8 Per Game
AACE15018	Cable Assy, Panel Stick Light From Board	A5CB5190A	PCB, Sensor
AACE15019	Cable Assy, Center Panel Stick Light Pwr	AACB9600A	PCB, Audio Amplifier Board
AACE15020	Cable Assy, Center Split To Panel Lights	AACB10000	Board, PCB, C4 Hoops Controller
AACE15042	Cable Assy, Line Filter From Power Box	AACB5156	PCB, Power Dist. Board
AACE15022	Cable Assy, Line Filter Center Connection	AACB9604	Board, Door Interface Board
AACE15043	Cable Assy, Line Filter To Power Strip	AAMB10E-HD	Mother Board,Qc5000-Itx/Ph W/Hard Drive
AACE15024	Cable Assy, Power Supply Grd To Main Brd	WACA15014	Front Clear Plexi Ball Guard
AACE15025	Cable Assy, Right Coin Door Ground	WACA15090	Basket Hoop Etched Plexi
AACE15026	Cable Assy, Left Coin Door Ground	AACB15001	Bleed Resistor Board
AACE15027	Cable Assy, Left Ticket Dispenser Ground	A5CORD5001	Power Cord 2 feet
AACE15028	Cable Assy, Right Ticket Dispenser Ground	A5CORD5003	Power Cord, 6 feet
AACE15036	Cable Assy, Hoop Sensor		

## PARTS PICTURES



A5BA15000



AABK1013



A5BK9999




A5CB2050



A5FI9010



A5HO1003




A5LK2001



# PARTS PICTURES



A5LK5002



A5LV10000



A5OU5000



A5PL4200




A5PL8900



A5SSL020




A5SREX050



AASW200



A5VF4604



AACO1020




W5HG1025




W5HG1030



W5HG1040



W5HG1065




W5KE5000



W5TM4000



A5DE15000



A5DE15001



A5DE15002



A5DE15003



A5DE15004



A5DE15005



A5DE15006



A5DE15007



A5DE15008



A5DE15009



A5DE15010



A5DE15011



A5DE15012



A5DE15013



A5DE15014-1



A5DE15014-2



A5DE15020



A5DE15021



A5DE15015-1



A5DE15015-2




A5DE15016



A5DE15019



A5DE10021




A5ME10001



A5ME1727



A5ME4179



A5CBL4A-DOOR



A5CBL5900



A5CE2300



A5CE6601



A5CEAU010



A5CORD1



A5CORD23



A5CORD36



A5CORD5-A



AACE15000



# PARTS PICTURES



**AACE15001**



**AACE15002**



**AACE15003**




**AACE15005**



**AACE15006**



**AACE15007**



**AACE15008**



**AACE15009**



**AACE15010**



**AACE15011**



**AACE15012**



**AACE15013**



**AACE15014**



**AACE15015**



**AACE15016**



**AACE15017**



**AACE15018**



**AACE15019**



**AACE15020**



**AACE15022**



**AACE15024**



**AACE15025**



**AACE15026**



**AACE15027**



**AACE15028**



**AACE15036**




**AACE15037**



**AACE15038**



**AACE15039**



**AACE15040**



**AACE15041**



**AACE1710**



**AACE1715**



**A5MO5154**



**A5PS1013**



**A5TD1**



**AACE8811**



**AAPB2700**



**A5CB5190A**



**AACB9600A**



**AACB10000**



**AACB5156**



# DECAL DIAGRAM

## CONNECT 4 HOOPS HD DECAL DIAGRAM

A5DE15010\_CABINET SIDE-LEFT TOP

A5DE15012\_CABINET SIDE-RIGHT TOP  
*NOT VISIBLE IN PHOTO*

A5DE15019\_MARQUEE

A5DE15001\_BACKBOARD

### FRONT CABINET

A5DE15016\_FRONT COVER

A5DE15000\_SPEAKER PANEL

A5DE15009\_PLATFORM RIGHT

A5DE15008\_PLATFORM LEFT

A5DE15007\_MECH DOOR RIGHT

A5DE15006\_MECH DOOR LEFT

A5DE15021\_SHELF RIGHT

A5DE150206\_SHELF LEFT

A5DE10021\_CAUTION\_TROUGH

A5DE15002\_CABINET FRONT

A5DE15004\_DOOR RIGHT

A5DE15005\_DOOR CENTER

A5DE15003\_DOOR LEFT

A5DE15014-2\_CABINET SIDE PANEL- LEFT TOP

A5DE15014-1\_CABINET SIDE PANEL- LEFT BOTTOM

A5DE15015-2\_CABINET SIDE PANEL- RIGHT TOP

*NOT VISIBLE IN PHOTO*

A5DE15015-1\_CABINET SIDE PANEL- RIGHT BOTTOM

*NOT VISIBLE IN PHOTO*

A5DE15011\_CABINET SIDE-LEFT BOTTOM

A5DE15013\_CABINET SIDE-LEFT BOTTOM  
*NOT VISIBLE IN PHOTO*

## REPAIR/MAINTENANCE LOG

If you need to make repairs or order replacement parts it is a good idea to keep a log. Below is a chart you can use to track repairs and maintenance.

[illegible]

## NOTES

[illegible]



# TECHNICAL SUPPORT

Excellent customer service is very important to Bay Tek Entertainment! We know that keeping your games in great operating condition is important to your business. When you need us, we are here to help. You can call us for free technical assistance, and you can count on us to have parts on-hand to support your game. When you do need us, it's important that you know what to expect.

We offer options that fit your needs.

## Electronics / Circuit Boards:

· **Repair & Return** – If you have Circuit Board issues with your Bay Tek product you can send the board to us and we'll repair it right away. Most items sent to us are repaired and returned to you within two days. This option is your best value as we offer this fast turn-around service at the most reasonable price.

· **Advance Replacement** – If you have Circuit Board issues with your Bay Tek product, but you don't have time to send in your board in for repair, give us a call and ask for an Advance Replacement. We'll send you a replacement board that same day (pending availability). When you get your new board, just repackage the defective board in the same box and send it back to us. We make it easy by including a UPS Return-Shipping label for you to put on the box.

This is your best option when you need to get your game up and running as quickly as possible!

· **Spare Parts** – Take matters into your own hands and purchase new spare Circuit Boards for your Bay Tek games. Many of our games share the same main-board electronics. This means you can buy one set of spare electronics to support many of your Bay Tek games. Spare boards allow you to get your game up and running the quickest and provide you a valuable troubleshooting option. Call our technicians to get recommendations for what you should keep on hand for spare parts!

## Technical Support:

"You" are the best tool for troubleshooting! Your abilities to understand the game and your skills to repair the game are invaluable to us! If you need help, you know you can call us. It's not easy to diagnose a game remotely by phone, but our technicians do a great job. They'll need your help to perform some

troubleshooting steps and convey to them exactly what's happening with your game.

## Returns & Credits:

Sometimes the issue isn't what it seemed to be. If you chose the Advance Replacement option and now need to return that circuit board, just give us a call to get Return Authorization. You will be credited for the cost of the board and charged only the bench fee for our processing and retesting that board. If you choose the Repair and Return option, we'll test your board before we begin. If no problems are found, you will only be charged the bench fee.

*Note: Bench fees apply regardless of whether the repair was your choice or a recommendation from a Bay Tek Entertainment technician.*

*It's a small price to pay for troubleshooting the issues with your game.*

**You can count on our Technical Support Team for service and support!**



# WARRANTY OPTIONS

Bay Tek Entertainment warrants to the original purchaser that the game will be free of defects in workmanship and materials for a period of 2 years from the date of shipping.

Bay Tek Entertainment will, without charge, repair or replace at it's option defective product or component parts upon notification to the parts/service department.

Warranty replacement part(s) will be shipped immediately via ground service, along with a Return Material Authorization (RMA) number for the return of defective part(s). Defective part(s) must be shipped back to Bay Tek Entertainment unless otherwise instructed.

***This warranty does not apply in the event of any misuse or abuse to the product, or as a result of any unauthorized repairs or alterations. The warranty does not apply if the serial number decal is altered, defaced, or removed from it's original position.***

Should you need your game serviced, determine the serial number from the decal on the back of the game cabinet or main board, and call **920.822.3951 Ext. 1102**  
or e-mail to: [service@baytekent.com](mailto:service@baytekent.com)

# REPAIR OF NON-WARRANTY PARTS

Should your game need servicing, determine the serial number from the decal on the back of the game cabinet, inside front door, or the cover of this manual and call **920.822.3951 Ext. 1102**  
or e-mail to: [service@baytekent.com](mailto:service@baytekent.com)

An estimate of the repair charges will be quoted to you for approval.  
You may now proceed in one of two ways.

## Option 1:

Request immediate shipment of advance replacement part(s).

You will receive the part(s) with  
an **RMA** for the return of the faulty part(s).

***You must return the faulty part(s) in 14 days to avoid additional charges.***

## Option 2:

Call the Service Dept at (920) 822-3951 Ext. 1102 to receive a RMA to send the  
faulty part(s) in for repair

Please include the following information

**NAME**

**ADDRESS**

**PHONE #**

**SERIAL #**

**PURCHASE ORDER NUMBER** or

**AUTHORIZATION** to perform service.

Repaired part(s) will be shipped back using the same method in which they were received.

Repairs are warranted for 30 days from the date of installation.



# CONNECT 4 HOOPS HD PARTS LIST

## Parts List:

**Large Pallet** 76"x 54"x 86" 860 lbs. class 125

2 Side Cages Part 5 (Part # AAME15019)

Middle Cabinet Part B

Lower Rear Cabinet Part N

Cardboard Box # 2 (76 1/2" by 30" by 9 1/2")

(Box packed in this order:)

Right Side Front Upright Part H



Left Side Front Upright Part K

Top Front Part L

2 of Wood Corner Pieces Part J

2 of Front Top Connector Plate Part 4 (Part # A5ME15001)

Round Marquee Assembly  
Part P



**Small Pallet** 76"x 34"x 86" 410 lbs. class 250

Front Console Part M

6 Game Balls (Part # A5BA15000)

Service Manual

Hardware Kit (Part # A5KIT-HOOPS/HD)

AC Power Cord (Part # A5CORD5-A)

Game keys

Upper Rear Cabinet Part O

Wood Platform Part A

Cardboard Box # 1 (64" by 30" by 7")

(Box packed in this order:)

Front Windshield (Part # WACA15014)

3 of Game Roof Boards Part G

Left Side of Middle Section Part E

Right Side of Middle Section Part F

Wood Diverter Part C

Wood Diverter Part D

2 of Rear Connector Plates Part 1 (Part # A5ME15010)

2 of Middle Connector Plates Part 2 (Part # A5ME15004)

2 of Middle Connector Plates Part 3 (Part # A5ME15004)

