



COIN/SPLIT CABINET SOCCER PLAYFIELD REPLACEMENT

Tools Required:

- ELECTRIC DRILL WITH 9/64" BIT
- PHILLIPS SCREWDRIVER
- RIGHT ANGLE PHILLIPS SCREWDRIVER
- ALL-PURPOSE CLEANER (Fantastik, Formula 409, Windex or equivalent)
- CLEAN CLOTH
- Have two people carefully remove the top half of the cabinet and turn it upside down on a soft surface such as carpeting. Be <u>very careful</u> not to scratch the table in the process.
- 2. Remove the two Aluminum Playfield Supports by removing the Phillips head screws and Black Carriage Bolts.
- 3. Remove the playfield
- 4. Using a scraper, very carefully remove the black weather stripping
- 5. Apply new weather stripping to the underside of the Bearing Walls and Goal Walls.
- 6. Carefully install the new playfield then place the original playfield atop the new playfield to use as a template to drill mounting holes using the 9/64" bit.
- 7. Bolt the Aluminum Channel into the Top Half of the Cabinet.
- 8. Install the Phillips head screws
- 9. Have two people carefully turn the cabinet top half right side up and re-install on cabinet bottom half.
- 10. Thoroughly clean the playfield and install the playfield trim.

